

# **Eezi Awn drilling guide for 2.5m Awning Tent Kit**

## **Tools required**

**Sharp Pencil**

**Measuring tape or steel ruler**

**Centre punch**

**6mm drill bit with drill stop that will only allow 10 mm of the drill bit to protrude**

**Drill**

**An Authorized trained personnel to use the above tools**

## **Alloy box end**

**Set up the awning**

**From the grey end cap measure in 170mm and mark down.**

**From the top edge of the folded down section where the 170mm mark is measure down 30mm and mark across.**

**Repeat on other end of box**

## **Retractable End**

**From the grey end cap Measure in 90mm and mark down**

**From the roof material measure down 20mm where the 90mm mark is and mark across**

**Repeat on other end**

**Centre punch all hole marks**

**Drill all 4 holes with 6mm drill bit with drill stop (to stop damage to retractable mechanism)**